



# DAIKOWM 323S



CAST IRON  
NiFe-Cl

## DESCRIPTION

### Tubular wire rod for welding and repairing graphitic cast irons

It is a tubular wire which deposit an alloy of Fe-Ni type. It is suitable for joining and repairing all types of grey cast iron, also for joining cast iron with steel, but especially for nodular cast iron. The colour of the deposit is very similar to the base material and corrosion will be identical to the base material later on. To limit internal stress of the base metal, hammering of the beads is recommended after each pass.

## SPECIFICATIONS

AWS A5.15	ENiFe-Cl	Shielding	I1, M13
Positions	PA, PB, PC, PD, PE, PF, PG	Current	DC+
Packaging Type	Drums, B300, D200 and D100 spools.		

## HARDNESS

160HB - 180HB

## CHEM. COMP. %

C	0.08
Mn	4
Ni	Bal
S	0.02
Si	0.9
Fe	40

## MECHANICAL PROPERTIES

	PRODUCT
Tensile strength $R_m$ MPa	480
Yield strength $R_{p0.2}$ MPa	340
Elongation A ( $L_0=5d_0$ ) %	10

## WELDING PARAMETERS

	1.0 mm	1.2 mm
Ampere	170A - 210A	180A - 220A
Voltage	24V - 28V	26V - 30V
Packaging	Ø 0,8÷1,6mm	Ø 0,8÷1,6mm
Packaging Type	Drums, B300, D200 and D100 spools.	Drums, B300, D200 and D100 spools.





# NiFe-CI

## DESCRIPTION

CAST IRON  
NiFe-CI

### APPLICATION

The NiFe alloy is designed to weld various types of cast iron, with a particular focus on spheroidal graphite (SG), nodular or ductile cast irons, as well as some special cast iron alloys. This alloy provides an optimal combination of strength, ductility, and toughness, while ensuring good workability. NiFe consumables are versatile and can also be used on certain high-alloy austenitic cast irons (Ni-Resist). For flake graphite cast iron grades, preheating of 300-350 °C is recommended; however, for SG grades, a buttering procedure using low heat input and low temperature techniques is advised to avoid hot cracking in the heat affected zones (HAZ). It is important to note that Ni-Hard martensitic and white cast irons are generally unweldable due to their high susceptibility to cracking. NiFe consumables are also ideal for creating transition joints between cast iron and cast steels or between cast iron and mild/low-alloy steels. Common components include \*\*machine bases, pump bodies, engine blocks, gears, and gearbox housings\*\*.

### ALLOY TYPE

Nominally Fe-40% Ni alloy for the repair and joining of cast iron.

### MICROSTRUCTURE

The structure depends on the chemical composition and the speed of solidification and subsequent cooling down.

### MATERIALS

The NiFe weld metals produce higher strength than the pure nickel cast iron types and are therefore preferable for dissimilar joints, higher strength cast irons and spheroidal graphite cast irons.

**EN W.Nr.:** 1563:2018 Spheroidal graphite cast irons, 1562:2019-06 Malleable cast irons

**ASTM:** A602, A47, A338, A220

### WELDING & PWHT

In many cases, welding can be performed without preheating; however, for heavy multi-pass deposits or joints with high constraints, preheating between 150-250 °C may be necessary. Prior to welding, surfaces must be prepared by gouging and/or grinding, minimizing heat input to prevent crack propagation. It is essential that the area to be welded is as free from contaminants like sand, oil, grease, paint, or rust as possible. Preheating can be helpful in eliminating oil impregnated in castings to be repaired. If proceeding without preheat, it is preferable to limit the width of the HAZ using low heat input and low interpass temperature welding techniques. Using a fractional welding technique can be advantageous. For welding of thicker sections or with high constraints, preheating in the range of 150-250 °C might be necessary. Additionally, light peening to reduce contraction stresses can be beneficial, but it's crucial not to compromise the ductility of the weld metal. Buttering of the joining faces or sides of the repair cavity is also recommended before completion, regardless of the preheat applied. After welding, gradual cooling of the piece, with insulation if necessary, is highly recommended.

